

Assembly instruction for the following lounge chair & Sofa- with fully upholstered WOOD shell:





Products:

- Upholstered Beetle shell (Lounge or Sofa)
- 4-leg steel base (Lounge or sofa)
- 2x (3x for sofa) front: M5x30 black (DIN 912 / ISO 4762)
- 2x (3x for sofa) back: M5x25 black (DIN 912 / ISO 4762)
- 4x QuickClick Base Ø14 (Wagner part no: 15 8117 01)
- 4x QuickClick Black slim insert Ø20 (Wagner part no: 15 8289 01)
- 4x Countersunk self-drilling screw ST2,9 x 9,5 ZP (DIN 7982-C-H)

Tools:

Akku drill or Unbraco key size 4 + Torx size 10. Loctite medium strength (Würth DOS thread locking agent MEDIUM, Art. No. 0893243050)

Mounting glides on frame

Products:

- 4x QuickClick Base Ø14 (Wagner part no: 15 8117 01)
- 4x Countersunk self-drilling screw ST2,9 x 9,5 ZP (DIN 7982-C-H)
- 4x QuickClick Black slim insert Ø20 (Wagner part no: 15 8289 01)





BEETLE Lounge chair and sofa

Assembly instruction

Products:

4x QuickClick Base Ø14 Action: Place the QuickClick bases on the legs. Make sure the countersunk hole is visible (like the picture)

Products:

4x Countersunk self-drilling screw ST2,9 x 9,5 ZP (DIN 7982-C-H)

Action:

Mount the screw into the frame – to fasten the QuickClick bases to the frame.

NB. Maximum torque 1,4 Nm

Products:

4x QuickClick Black slim insert Ø20 Action: Place the Quick click inserts on the ground and the feet

(with mounted QuckClick bases on) on top.

Action:

Apply force until you hear a "CLICK" from the feet. The feet are now mounted – repeat for all 4 legs.













BEETLE Lounge chair and sofa

Assembly instruction



Products:

4-leg wooden upholstered shell Loctite

Action:

Turn the Beetle shell upside down and apply Loctite in the 4x M5 holes (6x M5 holes for sofa).

Products:

Upholstered Beetle shell (lounge or sofa). Steel chair base.

Action:

Place the steel base on top of the shell, so the 4 holes (6 holes for sofa, 2 extra hole in the middle of the shell) on the base are above the holes in the shell.

Products:


2x front (3x for sofa): M5x30 black 2x back (3x for sofa): M5x25 black

Action:


Please place the base **exactly** as on the picture. The 2 bend as the one marked with the **red arrows** on the picture, **shall** be placed forward on the shell.

(The mounting holes have different distance – so if the screw holes do not fit, you might have turned the frame the wrong way.)









BEETLE Lounge chair and sofa

Action:

Mount the 2x M5x25 (3x for sofa) screws in the back and 2x M5x30 (3x for sofa) screws in the front (higher mounting towers).

Important: Do not tighten the screws before all 4 pcs (or 6pcs for sofa) screws have been inserted to the thread.

NB. Maximum torque 10 Nm. NB. Screw needs to be firmly mounted

Action:

Turn the lounge chair/sofa back up and place it on the legs.

The Beetle chair is ready for use.



GUB



