


## Instructions

- 1. Move the hands to the correct time using the adjustment wheel on the back of the clock mechanism.
- 2. Insert 1x AA/LR6 battery (not included), as illustrated. We recommend the use of top condition, branded, alkaline batteries. Old or poor quality batteries may cause your clock to lose time/stop.



3. Where a clock is to be wall mounted, please ensure an adequate wall fixing is used to hang your clock, taking into account the type of wall and weight of the clock.

## **Care and Caution**

Please keep your clock out of direct sunlight. When you come to clean your clock please use a soft dry cloth as the use of liquids and cleaning agents may damage the finish.